





Side View - Scissor Open
1/8" = 1"



Frame Notching




Top Cylinder Block - 3/4" or 1" Thick Steel
(Typical of 1 - Flat-11)



Scissor Pivot Plates - 1/4" Thick Angle Steel
(Typical of 2 - Angle-4 & 5)

Step 10:



- 10.0 Weld Flat-17 and 18 to the sides of the assembly.
- 10.1 Drill, Tap and install a 1/4"-28 grease fitting into the bottom of the assembly. Be sure to drill through both Angle-4 and Pipe-7.
- 10.2 Ensure that Pipe-1 fits through Pipe-7 of the assembly without snagging or binding.

Scale:

Sample Plan

SAMPE
Page: x of x